

**DESC Standard DNP Metering Point List**

Below is the standard DNP metering point list DESC maps to the customer. If you have any questions concerning this list, please contact Jay Cole at [jay.cole@dominionenergy.com](mailto:jay.cole@dominionenergy.com).

1	Ia @Primary Jemstar	Analog
2	Ib @Primary Jemstar	Analog
3	Ic @Primary Jemstar	Analog
4	Total Amperage @Primary Jemstar	Analog
5	Va LineNeutral @Primary Jemstar	Analog
6	Vb LineNeutral @Primary Jemstar	Analog
7	Vc LineNeutral @Primary Jemstar	Analog
8	SpareAnalog7	Analog
9	MW A Phase @Primary Jemstar	Analog
10	MW B Phase @Primary Jemstar	Analog
11	MW C Phase @Primary Jemstar	Analog
12	MW Total @Primary Jemstar	Analog
13	MVAR A Phase @Primary Jemstar	Analog
14	MVAR B Phase @Primary Jemstar	Analog
15	MVAR C Phase @Primary Jemstar	Analog
16	MVAR Total @Primary Jemstar	Analog
17	THD A Phase @Primary Jemstar	Analog
18	THD B Phase @Primary Jemstar	Analog
19	THD C Phase @Primary Jemstar	Analog

1	KWH received @Primary Jemstar	Counter
2	KWH delivered @Primary Jemstar	Counter
3	KVARH received @Primary Jemstar	Counter
4	KVARH delivered @Primary Jemstar	Counter